



Mast Moment Indicator

Displays mast moment



Amps of Battery

Displays Amp load for Battery



Displays Fuel Pressure for Engines

Fuel Pressure in kp/cm² for engines



Fuel Display for Main & Supply Tank

Displays current tank level in gallons for the Main Tank and the Supply Tank



Oil Pressure

Displays the oil pressure in kp/cm² (ATM) for Engines and Transmission



Oil Temperature

Displays the oil temperature in Deg C for Engines and Transmission



Oil Pressure and Temperature in Helicopter Transmission

Displays the oil pressure in psi and oil temperature in Deg C in transmission



Twin Turbine RPM (N2) and Rotor RPM

Displays RPM (N2) of Turbine 1 and Turbine 2 and the Rotor RPM in Percent



Torque of Helicopter Engine

Displays the torque of the helicopter engine in percent



Turbine Out Temperature for Turbine (1 or 2)

Displays the Turbine Outlet Temperature in Deg C